



# ***New Product Information***

## **SHIFT CABLE REPAIR CLIP KIT**

### **KT04981**

*also available individually... part number below image.*

These snap-in replacement grommets are designed to allow you to repair a shift cable without having to remove the cable from your vehicle. *Easy as 1,2,3*

1. Select the grommet needed for your application.
2. Install the grommet into the shift cable as instructed.
3. Snap the cable back onto the shift lever until it clicks into place.



### **T74498-1**

Fits: GM & FORD vehicles that have a "Straight" shaft on the shift lever.



### **T74498-1A**

Fits: GM vehicles that have a "Ball" or "Bell" shaft on the shift lever.

**NEW**



### **T76498-1**

Fits: Most FORD Trucks ('97-'08) & Explorer, Expedition, Navigator and Mountaineer ('02-'05)

**NEW**



### **T92498-1**

Fits: ('05-'15) CHRYSLER, DODGE, & JEEP with 41TE or 62TE transmission.

**REQUEST THE BEST... ASK FOR GENUINE TECKPAK-FITZALL**  
**1-800-527-2544**      **www.teckpak-fitzall.com**